

Technical Information Manual

Revision n. 9
May 24th, 2024

MOD. N957


*8K MULTICHANNEL
ANALYZER*

NPO:
00105/04:N957x.MUTx/09

Register your device

Register your device to your **MyCAEN+** account and get access to our customer services, such as notification for new firmware or software upgrade, tracking service procedures or open a ticket for assistance. **MyCAEN+** accounts have a dedicated support service for their registered products. A set of basic information can be shared with the operator, speeding up the troubleshooting process and improving the efficiency of the support interactions.

MyCAEN+ dashboard is designed to offer you a direct access to all our after sales services. Registration is totally free, to create an account go to <https://www.caen.it/become-mycaenplus-user> and fill the registration form with your data.



<https://www.caen.it/become-mycaenplus-user/>

Limitation of Responsibility

If the warnings contained in this manual are not followed, CAEN will not be responsible for damage caused by improper use of the device. The manufacturer declines all responsibility for damage resulting from failure to comply with the instructions for use of the product. The equipment must be used as described in the user manual, with particular regard to the intended use, using only accessories as specified by the manufacturer. No modification or repair can be performed.

Disclaimer

No part of this manual may be reproduced in any form or by any means, electronic, mechanical, recording, or otherwise, without the prior written permission of CAEN spa.

The information contained herein has been carefully checked and is believed to be accurate; however, no responsibility is assumed for inaccuracies. CAEN spa reserves the right to modify its products specifications without giving any notice; for up to date information please visit www.caen.it.

Made in Italy

We remark that all our boards have been designed and assembled in Italy. In a challenging environment where a competitive edge is often obtained at the cost of lower wages and declining working conditions, we proudly acknowledge that all those who participated in the production and distribution process of our devices were reasonably paid and worked in a safe environment (this is true for the boards marked "MADE IN ITALY", while we cannot guarantee for third-party manufactures).



TABLE OF CONTENTS

LIMITATION OF RESPONSIBILITY	3
DISCLAIMER	3
MADE IN ITALY.....	3
1. GENERAL DESCRIPTION	10
1.1 OVERVIEW	10
2. TECHNICAL SPECIFICATIONS	11
2.1 PACKAGING	11
2.2 POWER REQUIREMENTS	11
2.3 FRONT AND BACK PANEL	12
2.4 INPUT/OUTPUT CONNECTIONS	13
2.5 FRONT PANEL DISPLAYS	13
2.6 INTERNAL HARDWARE COMPONENTS	14
2.6.1 <i>Switches</i>	14
2.6.2 <i>Firmware jumpers</i>	14
2.7 TECHNICAL SPECIFICATION TABLE	15
2.8 ANALOG TO DIGITAL CONVERSION	16
2.8.1 <i>Analog to digital conversion timing</i>	17
2.8.2 <i>Pile Up Rejection</i>	19
2.9 DATA READOUT	20
2.10 SCALER AND TIMERS	21
2.10.1 <i>Scaler description</i>	21
2.10.2 <i>Timers description</i>	21
2.11 FIRMWARE UPGRADE	23
2.11.1 <i>N957Upgrade command parameters</i>	24
3. SOFTWARE INTERFACE	25
3.1 REGISTER MAP	25
3.2 STATUS REGISTER (0x00, R)	26
3.3 CONTROL REGISTER (0x01, R/W)	26
3.4 FIRMWARE REVISION REGISTER (0x02, R)	27
3.5 FIRMWARE DOWNLOAD REGISTER (0x03, R/W)	27
3.6 FLASH ENABLE REGISTER (0x04, R/W)	27
3.7 PULSER REGISTER (0x05, R/W)	27

3.8	DAC REGISTER (0x06, R/W)	27
3.9	BLOCK DIMENSION REGISTER (0x07, R/W).....	27
3.10	POTENTIOMETER CONTROL REGISTER (0x08, R/W).....	28
3.11	CALIBRATION SET REGISTER (0x09, W)	28
3.12	CALIBRATION CLEAR REGISTER (0x0A, W)	28
3.13	SCRATCH REGISTER (0x0B, R/W).....	28
3.14	BUFFER OCCUPANCY REGISTER (0x0C, R/W)	28
3.15	SCALER LOW REGISTER (0x0D, R)	28
3.16	SCALER HIGH REGISTER (0x0E, R).....	28
3.17	TIMER LOW REGISTER (0x0F, R/W)	29
3.18	TIMER HIGH REGISTER (0x10, R)	29
3.19	LIVETIME LOW REGISTER (0x11, R).....	29
3.20	LIVETIME HIGH REGISTER (0x12, R)	29
3.21	SOFTWARE CLEAR REGISTER (0x13, W)	29
3.22	SOFTWARE RESET REGISTER (0x14, W).....	29
4.	SOFTWARE TOOLS.....	30
4.1	SOFTWARE INSTALLATION: GETTING STARTED.....	31
4.1.1	<i>Software installation: Windows</i>	31
4.1.1.1	Software installation: Demo folder	31
4.1.1.2	Software installation: Doc folder.....	31
4.1.1.3	Software installation: LabView folder	31
4.1.1.4	Software installation: Lib Folder.....	31
4.1.1.5	Software installation: Upgrade folder	32
4.1.2	<i>Driver installation (Windows)</i>	33
5.	LIBRARY AND DEMO SOFTWARE OVERVIEW.....	34
5.1	N957TOOL LIBRARY	34
5.1.1	<i>N957Tool library: Overview</i>	34
5.1.2	<i>N957Tool library: typical usage</i>	35
5.2	DEMO SOFTWARE.....	36
5.2.1	<i>Demo software: N957Demo</i>	36
5.2.1.1	N957Demo: overview.....	36
5.2.1.2	N957Demo: settings.....	36
5.2.1.3	N957Demo: configuration file format	37
5.2.1.4	N957Demo: output data format	38

5.2.1.5	N957Demo: practical example	39
6.	TECHNICAL SUPPORT	42

LIST OF FIGURES

FIG. 1.1:	MOD. N957 BLOCK DIAGRAM	10
FIG. 2.1:	MOD. N957 FRONT PANEL	12
FIG. 2.2:	MOD. N957 PCB BOARD AND COMPONENT LOCATION	14
FIG. 2.3:	SIGNAL CONVERSION TIMING AUTO GATE MODE (NO PILEUP)	18
FIG. 2.4:	SIGNAL CONVERSION TIMING AUTO GATE MODE (TRAILING EDGE PILEUP)	18
FIG. 2.5:	SIGNAL CONVERSION TIMING EXTERNAL GATE MODE.....	19
FIG. 2.6:	PUR TIMING FOR EVENT REJECTION (AUTO GATE MODE)	19
FIG. 2.7:	MAX DATA RATE VS. DATA BLOCK SIZE SETTING	20
FIG. 2.8:	LIVETIME STATUS (CONTROL REGISTER <0> = 1 AND AUTO GATE MODE)	22
FIG. 2.9:	LIVETIME STATUS (CONTROL REGISTER <0> = 1 AND EXTERNAL GATE MODE)	22
FIG. 4.1:	INSTALLATION FOLDER STRUCTURE	31
FIG. 4.2:	PROGRAM MENU DEMO	32
FIG. 4.3:	USB DRIVER INSTALLED.	33
FIG. 5.1:	SOFTWARE LAYERS.....	34
FIG. 5.2:	N957DEMO PROMPT	39
FIG. 5.3:	N975DEMO IN ACQUISITION MODE.....	39
FIG. 5.4:	HISTOGRAM PLOT OF ⁶⁰ Co SOURCE IN PROGRESS.....	40
FIG. 5.5:	ACQUISITION REPORT	40



LIST OF TABLES

TABLE 2.1:	POWER REQUIREMENTS	11
TABLE 2.2:	MOD. N957 TECHNICAL FEATURES	15

Safety Notices

N.B. Read carefully the “Precautions for Handling, Storage and Installation” document provided with the product before starting any operation.

The following HAZARD SYMBOLS may be reported on the unit:

	Caution, refer to the product manual
	Caution, risk of electrical shock
	Protective conductor terminal
	Earth (Ground) Terminal
	Alternating Current
	Three-Phase Alternating Current

The following symbol may be reported in the present manual:

	General warning statement
---	---------------------------

The symbol could be followed by the following terms:

- **DANGER:** Indicates a hazardous situation that, if not avoided, will result in serious injury or death.
- **WARNING:** Indicates a hazardous situation that, if not avoided, could result in death or serious injury.

CAUTION: Indicates a situation or condition that, if not avoided, could cause physical injury, or damage the product and/or its environment.

GENERAL NOTICES:

CAUTION: Avoid potential hazards.



USE THE PRODUCT ONLY AS SPECIFIED.

ONLY QUALIFIED PERSONNEL SHOULD PERFORM SERVICE PROCEDURES

CAUTION: Avoid Electric Overload.



TO AVOID ELECTRIC SHOCK OR FIRE HAZARD, DO NOT POWER A LOAD OUTSIDE OF ITS SPECIFIED RANGE

CAUTION: Avoid Electric Shock.



TO AVOID INJURY OR LOSS OF LIFE, DO NOT CONNECT OR DISCONNECT CABLES WHILE THEY ARE CONNECTED TO A VOLTAGE SOURCE

CAUTION: Do Not Operate in Wet/Damp Conditions.



TO AVOID ELECTRIC SHOCK, DO NOT OPERATE THIS PRODUCT IN WET OR DAMP CONDITIONS

CAUTION: Do Not Operate in an Explosive Atmosphere.



TO AVOID INJURY OR FIRE HAZARD, DO NOT OPERATE THIS PRODUCT IN AN EXPLOSIVE ATMOSPHERE



THIS DEVICE SHOULD BE INSTALLED AND USED BY A SKILLED TECHNICIAN ONLY OR UNDER HIS SUPERVISION



**DO NOT OPERATE WITH SUSPECTED FAILURES.
IF YOU SUSPECT THIS PRODUCT TO BE DAMAGED, PLEASE CONTACT THE TECHNICAL SUPPORT**

NIM NOTICES:

CAUTION: This product needs proper cooling.



**USE ONLY CRATES WITH FORCED COOLING AIR FLOW SINCE
OVERHEATING MAY DEGRADE THE MODULE PERFORMANCES!**

CAUTION: This product needs proper handling.



**THIS DIGITIZER DOES NOT SUPPORT LIVE INSERTION (HOT-SWAP)!
REMOVE OR INSERT THE BOARD WHEN THE CRATE IS POWERED OFF!**



**ALL CABLES MUST BE REMOVED FROM THE FRONT PANEL BEFORE
EXTRACTING THE BOARD FROM THE CRATE!**

1. General description

1.1 Overview

The Mod. N957 is a 8k Multi-Channel (MCA) with USB port, housed in a 1-unit wide standard NIM module. The multichannel analyzer performs the essential function of collecting the data and producing output, in the form of converted value of input peaks.

The input pulses can be those produced by a standard spectroscopy amplifier. They can be Gaussian, semi-Gaussian or square waves, unipolar (positive) or bipolar, in a range from 0 to 10 V, with a rise time greater than 0.1 μ s.

The trigger can be made "on signal" (Auto Gate mode) or "external" (External Gate mode). In the first case a discriminator, with a settable threshold, enables the conversion. In the second case, an external gate is fed to the module, via front panel GATE In connector.

The input channel has one peak amplitude stretcher, the output of which is digitised by a 13 bit fast (0.8 μ s) ADC featuring a sliding scale technique, to improve the differential non-linearity. Converted waveforms are stored into a 64 KSamples buffer memory.

The unit hosts an USB2.0 port (also compatible with USB 1.1), which permits a simple control and data-acquisition via PC.

Software Libraries, available for both Windows and Linux platforms, are described in § 5.

Future firmware upgrade is possible via USB; only tools developed by CAEN must be used for the firmware upgrade.




Fig. 1.1: Mod. N957 Block Diagram

2. Technical specifications

2.1 Packaging

The Model N957 is housed in a single width NIM module.

2.2 Power requirements

Table 2.1: Power requirements

+12 V	220 mA
-12 V	220 mA
+6 V	600 mA
-6 V	50 mA

2.3 Front and back panel




Fig. 2.1: Mod. N957 Front panel

2.4 Input/Output connections

IN:	Type: Input Function: Unipolar (positive) or bipolar in a range from 0 to +10 V, with a rise time greater than 0.1 μ s, high impedance. BNC connector (to be connected to Amplifier Analog output); negative inputs are neglected.
GATE:	Type: Input Function: Temporal window for peak detection (in External Gate mode); Signal must occur prior to and must extend for at least 0.2- μ s after the peak; NIM/TTL (automatically recognised) signal, high impedance. BNC connector.
BUSY:	Type: Output Function: Provides NIM/TTL (switch selected, see § 2.6.1) standard logic level signal to indicate a conversion;. Rise Time $\leq$ 3.5 ns. Fall Time $\leq$ 3.5 ns. LEMO connector.
CONV:	Type: Input Function: Accepts NIM/TTL (switch selected, see § 2.6.1) signal; it is an external conversion inhibit (active high), actually it disables the ongoing conversions. Input impedance: 50 Ohm; LEMO connector.
PUR:	Type: Input Function: Pile-up rejection input; accepts NIM/TTL (switch selected, see § 2.6.1) signal; signal must occur before the ADC Conversion (see § 2.8.2). Input impedance: 50 Ohm; LEMO connector (to be connected to Amplifier INHIBIT Output ¹).
OUTP:	Type: Output Function: Provides NIM/TTL (switch selected, see § 2.6.1) standard logic level signal programmable via USB. (OUTP default signal: BUFFER_FULL $\rightarrow$ data loss; it can be turned off by resetting the Full status flag, see § 3.3).
LINK:	B type USB connector; USB 2.0 compliant

2.5 Front panel displays

BUSY:	red LED; light up during the ADC conversion
PUR, OUTP:	green LEDs (1 per connector); light up as the relevant signal is active
CONV:	green LED; light up if CONVERSION ENABLE bit (see § 3.3) is ON and CONV input signal is not active.
LINK ON:	green LED; lights up as USB port is powered
TX/RX:	yellow LED; signals activity on USB port

¹ Amplifier INHIBIT Output provides a logic pulse when the internal pile-up rejection logic detects a distortion of the input signal due to pile-up.

2.6 Internal hardware components

See Fig. 2.2 for their exact location on the PCB and their settings.

2.6.1 Switches

SW1

Type: DIP switch.

Function: it allows the selection between NIM and TTL I/O signals (RIGHT: TTL; LEFT: NIM).

2.6.2 Firmware jumpers

J6

Type: Jumper.

Function: it allows to select whether the “Standard” or the “Back up” firmware must be loaded at power on; (default position: STD).




Fig. 2.2: Mod. N957 PCB board and component location

2.7 Technical specification table

Table 2.2: Mod. N957 Technical Features

No. of ADC channels	1
Input signals	Unipolar (positive) or bipolar, 300 mV ÷ 10 V range, rise time > 0.1 µs
Resolution	13 bit (8192 channels - 8064 valid if sliding scale enabled see 2.8)
ADC Conversion time	0.8 µs
Dead Time	4.8 µs
LSB	1.22 mV
Gate	Signal must occur prior to and must extend for at least 0.2-µs after the peak (in External Gate mode);
Maximum transfer rate	30 Mbyte/s (USB2.0); 75 Kbytes/s (USB1.1)
Differential Non-Linearity	< 1% from 5% to 95% of input FSR (500 mV ÷ 9.5 V)
Integral Non-Linearity	< 0.065% from 5% to 95% of input FSR (500 mV ÷ 9.5 V)
Gain Instability:	< +150 ppm/°C
USB port	Compatible with USB 1.1 and USB 2.0 30Mbyte/s (USB 2.0 Bulk Transaction Protocol) 3m maximum cable length (longer distance can be achieved with commercial off-the-shelf products)
I/O signals	NIM/TTL; selected via internal switch SW1 on PCB (see Fig. 2.2)
Discriminator Threshold	Software programmable, 0 mV ÷ 500 mV range, 100 steps

2.8 Analog to digital conversion

The input stage of the module is basically a linear stretcher which detects the input peak value, while the gate is active, and keeps such value until the end of conversion.

Conversion can be triggered automatically (Auto Gate mode) or externally (External Gate mode), depending on Control register setting (see § 3.3). In the first case a discriminator, with a threshold settable via N957_SetLLD function, enables the conversion, which is active as long as the input signal is above such threshold. In the second case, an external gate is fed to the module, via front panel Gate In connector.

The output of the peak section is converted by a 13 bit Fast ADC. The ADC section supports the sliding scale technique to reduce the differential non-linearity consists in adding a known value to the analog level to be converted, thus spanning different ADC conversion regions with the same analog value. The known level is then digitally subtracted after the conversion and the final value is sent to the threshold comparator.

If the sliding scale is enabled, it reduces slightly the dynamic range of the ADC: the 13-bit digital output is valid from 0 to 8063, while the values from 8064 to 8191 are not correct.

2.8.1 Analog to digital conversion timing

The signal conversion timing is shown in the following figures (Fig. 2.3, Fig. 2.4, Fig. 2.5); the diagram includes five different logic states:

- **Idle**
- **Track** (acquiring data phase)
- **Settling** (Settling time before ADC conversion)
- **Digitisation** (ADC Conversion)
- **Clear** (fast capacitor discharge in the peak section)

Idle state:

- Auto Gate mode: the input signal after threshold starts the Track (acquiring data) phase
- External Gate mode: the occurrence of a GATE pulse starts the Track (acquiring data) phase

Track (acquiring data) state

- Auto Gate mode: in the Track state the PEAK output increases according to the input signal. When the first peak is detected starts the Settling phase (where the peak value is held by means of a capacitor)
- External Gate mode: in the Track state the PEAK output increases according to the input signal until the highest peak within the GATE ON is reached. When the GATE signal become inactive starts the Settling phase (where the peak value is held by means of a capacitor)

Settling (Settling time before ADC conversion)

The peak value is held by means of a capacitor until the end of the digital conversion (digitisation) The Settling state takes about 2 μ s (settling time)

Digitisation state

During this phase the output of the PEAK section is converted by a 13 bit Fast ADC (the phase takes 0.8 μ sec)

Clear state

After the digital conversion, the clear phase takes place by a fast capacitor discharge (about 2 μ s) which makes the conversion logic idle again.




Fig. 2.3: Signal conversion timing Auto Gate mode (No Pileup)




Fig. 2.4: Signal conversion timing Auto Gate mode (Trailing Edge Pileup)




Fig. 2.5: Signal conversion timing External Gate mode

2.8.2 Pile Up Rejection

The PUR input signal prevents the ADC to store piled up events. It accepts NIM/TTL (switch selected, see § 2.6.1) signal. To reject an event, the PUR signal must occur before the conversion logic state Digitisation (before start of BUSY pulse) and must overlap the BUSY output signal (see Fig. 2.6).




Fig. 2.6: PUR timing for event rejection (Auto Gate mode)

2.9 Data readout

Converted peaks are stored into a 64 KSamples buffer memory, available for data readout via built-in USB2.0 interface (also compatible with USB1.1). Data rate depends, besides the connected PC capabilities, on the board setting via *N957_ReadData* function, which allows to read a data block of programmable size; the larger the block size, the faster the transfer rate.

The average transfer rate of the system can be evaluated in the following way:

- Enable software conversion via *N957_SetSwConvFlag* function
- Set the ADC sampling rate via *N957_SetADCRate* function
- Readout data via *N957_ReadData* function
- Acknowledge buffer occupancy via *N957_GetBufferOccupancy* function

During this procedure, the OUTP LED (in default setting) must not light up to signal that buffer memory is full.

N957_ReadData function always returns the number of readout data; converted waveforms are provided in the form of raw data, which have to be processed by the User's software tools.




Fig. 2.7: Max Data Rate Vs. Data Block Size setting

2.10 Scaler and Timers

The board houses one 32 bit scaler and two 32 bit timers (named **Timer** and **Livetime**).

2.10.1 Scaler description

Scaler counts the ADC conversion.

The Scaler is controlled by the bit 0 of the Control Register:

- Control Register <0> = 0: Scaler status: stop
- Control Register <0> = 1: Scaler status: count

The Scaler is cleared by the following operation:

- Dummy write access Software Clear register
- Dummy write access Software Reset register

Scaler read operation description:

1. Dummy write access Timer Low register: this operation freeze the value of Scaler L/H registers
2. Read the Scaler Low register: Scaler<15..0>
3. Read the Scaler High register: Scaler<31..16>

2.10.2 Timers description

Timer and Livetime input clock: 1 KHz

Timer is controlled by the bit 0 of the Control Register:

- Control Register <0> = 0: Timer status: stop
- Control Register <0> = 1: Timer status: count

Livetime is controlled by the bit 0 and 6 of the Control Register:

- Control Register <0> = 0: Livetime status: stop
- Control Register <0> = 1: Livetime status: enabled count
 - in Auto Gate mode (see Fig. 2.8):
 - Idle and Track status: count (if board is not full)
 - Settling, Digitisation and Clear status: stop
 - in External Gate mode (see Fig. 2.9):
 - Track and Settling status: count (if board is not full)
 - Idle, Digitisation and Clear status: stop




Fig. 2.8: Livetime status (Control Register <0> = 1 and Auto Gate mode)




Fig. 2.9: Livetime status (Control Register <0> = 1 and External Gate mode)

Timer and Livetime are cleared by the following operation:

- Dummy write access Software Clear register
- Dummy write access Software Reset register

Timer and Livetime read operation description:

1. Dummy write access Timer Low register: this operation freeze the value of Timer and Livetime L/H registers
2. Read the Timer Low register: Timer<15..0>
3. Read the Timer High register: Timer<31..16>
4. Read the Livetime Low register: Livetime <15..0>
5. Read the Livetime High register: Livetime <31..16>

2.11 Firmware upgrade

The board can store two firmware versions, called STD and BKP respectively; at Power On, a microcontroller reads the Flash Memory and programs the module with the firmware version selected via the J6 jumper (see § 2.6.2), which can be placed either on the STD position, or in the BKP position.

It is possible to upgrade the board firmware via USB, by writing the Flash: for this purpose, download the firmware package available on the board web page (**login required**):

The package includes the new firmware release file:

N957CTL_revXY.rbf

For upgrading the firmware, utilize the upgrade program situated in the folder described in paragraph in § 4.1.1.5; open a DOS Shell, then launch:

N957Upgrade -lfilename (filename= upgrade input file).

N.B.: it is strongly suggested to upgrade ONLY one of the stored firmware revisions (generally the STD one): if both revision are simultaneously updated, and a failure occurs, it will not be possible to upload the firmware via VME again!

2.11.1 N957Upgrade command parameters

N957Upgrade can be configured via command line through a set of parameters, described in the following.

The parameters format is as follows:

`-param_id[param_value]`

where:

- *param_id*: a character which identifies the parameter.
- *param_value*: value of the parameter, if foreseen by the parameter itself.

Notes about the parameters usage:

- If one parameter is not assigned, default value is assumed.
- The presentation order of the parameter is arbitrary:
- Each not recognised parameter is ignored
- Each parameter must be separated from the others via one or more spaces.

List of available parameters with relevant default value and usage example:

params_list:

- **-ifilename | -Ifilename**

filename= upgrade input file. If not specified 'N957.rbf' will be assumed.

example: N957Upgrade -i"N957_new.rbf"

 N957Upgrade -lupgrade.dat

- **-s | -S** upgrade standard flash page. Default flash page value is 'standard'.

example: N957Upgrade -s

- **-b | -B** upgrade backup flash page. Default flash page value is 'standard'.

example: N957Upgrade -b

- **-h | -H** show the help screen

example: N957Upgrade -h

3. Software interface

The module can be operated via a set of software accessible registers, whose description is reported in the subsequent sections.

3.1 Register map

REGISTER NAME	ADDRESS	MODE	FUNCTION
STATUS	0x00	R	Status register
CONTROL	0x01	R/W	Control register
FWREV	0x02	R	FPGA firmware revision
FWDWLND	0x03	R/W	R/W configuration rom data
FLENA	0x04	R/W	Flash enable
PULSER	0x05	R/W	SW pulse duration
DAC	0x06	R/W	DAC value setting
BLDIM	0x07	R/W	Data transfer block size
POTCTRL	0x08	R/W	Digital pot control register
CAL_SET	0x09	W	Digital pot bit set register
CAL_CLEAR	0x0A	W	Digital pot bit clear register
SCRATCH	0x0B	R/W	Scratch
BUFFER OCCUPANCY	0x0C	R	Buffer occupancy
SCALER_L	0x0D	R	Scaler (16 LSB)
SCALER_H	0x0E	R	Scaler (16 MSB)
TIMER_L	0x0F	R/W	Timer (16 LSB)
TIMER_H	0x10	R	Timer (16 MSB)
LIVETIME_L	0x11	R	Live Timer (16 LSB)
LIVETIME_H	0x12	R	Live Timer (16 MSB)
SW CLEAR	0x13	W	Software Clear
SW RESET	0x134	W	Software Reset

3.2 Status register (0x00, r)

Bit	Name	Function
3	FLASH BUSY FLAG	0 = Flash ready 1 = Flash busy
2	MEMORY FULL	0 = Data Memory is not full 1 = Data Memory has been filled (can be reset via SWR_RESET or FLAG CLEAR bit of CONTROL REGISTER)
1	MEMORY EMPTY	0 = Data Memory is not Empty 1 = Data Memory is Empty
0	USB TYPE	0 = Full Speed (USB 1.1) 1 = High Speed (USB 2.0)

3.3 Control register (0x01, r/w)

Bit	Name	Function	Default Value
15	OUTP LEMO LOGIC LEVEL	sets the OUTP logic level when OUTP MODE is "PROGRAMMABLE LEVEL"	0
13,14	OUTP LEMO MODE CONFIG	selects the signal to present on OUTP front panel connector 00 = MEMORY FULL (active high); default 01 = PEAK DETECT (active high when stretcher detects one peak) 10 = PROGRAMMABLE LEVEL (Logic level set by OUTP LEMO LOGIC LEVEL bit) 11 = PULSE MODE (Programmable width active high pulse when PULSER register is written)	00
12	SLIDING SCALE MODE SELECT	selects sliding scale type: 0 = Random mode (default) 1 = RAMP mode	0
11	DAC TEST MODE ENABLE	0 = DAC test mode disabled 1 = DAC test mode enabled. Sliding scale disabled and the sliding scale DAC is set with the DAC register value (see 0) – only for test purpose	0
10	RESERVED		-
9	ACQUISITION MODE	0 = External Gate mode 1 = Auto Gate mode (on discriminator threshold)	1
8	PUR INPUT ENABLE	0 = PUR input sensing disabled 1 = PUR input sensing enabled	1
7	SOFTWARE CONVERSION MODE ENABLE	0 = Software conversion mode disabled 1 = Software conversion mode enabled (the control FPGA auto generates conversion requests at a fixed periodic rate – only for test purpose)	0
6	CONVERSION ENABLE	enables ADC data storage into memory buffer for readout 0 = ADC data storage disabled 1 = ADC data storage enabled	0
5	FLAG CLEAR	0 = Rearms Memory Full Flag 1 = Forces Memory Full Flag Clear (see § 3.2)	0
4	SLIDING SCALE ENABLE	0 = Sliding Scale disabled 1 = Sliding Scale enabled	1
3..1	ADC SWR RATE	Selects ADC Conversion Rate when ADC Software Conversion is enabled 0 = 600 S/s 1 = 70 KS/s 2 = 140 KS/s 3 = 250 KS/s 4 = 420 KS/s 5 = 635 KS/s 6 = 850 KS/s 7 = 1 MS/s	7
0	Timers/scaler enable FLAG	0 = Scaler/Timers disabled 1 = Scaler/Timers enabled	0

3.4 Firmware revision register (0x02, r)

Bit	Name	Function
15..8	x	FPGA firmware revision (x.y)
7..0	y	FPGA firmware revision (x.y)

3.5 Firmware download register (0x03, r/w)

Bit	Name	Function
15..0	FLDATA	Allows to read/write words from/to the on-board flash memory. Must be accessed only through software library API calls.

Register default value = 0x0000.

3.6 Flash Enable register (0x04, r/w)

Bit	Name	Function
0	FLENA	Allows to enable the flash access for read/write operation. Should be accessed only through software library API calls

Register default value = 0.

3.7 Pulser register (0x05, r/w)

Bit	Name	Function
15..0	Pulse width	A write access to this register enables a PULSER signal on the board whose duration is equal to the value written. ($1.6 \mu s * \text{register value}$)

Register default value = 0x0000.

3.8 DAC register (0x06, r/w)

Bit	Name	Function
15..0	DAC value	Sets DAC value when module is in DAC TEST MODE (see § 3.3)

Register default value = 0x0000.

3.9 Block Dimension register (0x07, r/w)

Bit	Name	Function
15..0	BLDIM	Dimension of the next data block to read; write to BLDIM the number of samples that the User want to convert/read (through the USB port)

Register default value = 0x0020. (64 byte packet)

3.10 Potentiometer Control register (0x08, r/w)

Bit	Name	Function
7..0	POTCTRL	On board digital trimmer control register. Must be accessed only through software library API calls.

Register default value = 0x03.

3.11 Calibration Set register (0x09, w)

Bit	Name	Function
15..0	CAL SET	bit X : if 1, sets corresponding bit in Potentiometer Control register. Must be accessed only through software library API calls.

3.12 Calibration Clear register (0x0A, w)

Bit	Name	Function
15..0	CAL CLEAR	bit X : if 1, clears corresponding bit in Potentiometer Control register. Must be accessed only through software library API calls.

3.13 Scratch register (0x0B, r/w)

Bit	Name	Function
15..0	Scratch	Scratch register for test read/write accesses

Register default value = 0xAAAA..

3.14 Buffer Occupancy register (0x0C, r/w)

Bit	Name	Function
15..0	BUF_OCC	Occupancy level of the samples buffer (0-65535)

3.15 Scaler Low register (0x0D, r)

Bit	Name	Function
15..0	SCALER_L	Counter (bits 15..0) of performed conversions; enabled via Timers/scaler enable FLAG (see § 3.3)

3.16 Scaler High register (0x0E, r)

Bit	Name	Function
15..0	SCALER_H	Counter (bits 31..16) of performed conversions; enabled via Timers/scaler enable FLAG (see § 3.3)

3.17 Timer Low register (0x0F, r/w)

Bit	Name	Function
15..0	TIMER_L	Acquisition Real Time(bits 15..0); LSB=1ms. Enabled via Timers/scaler enable FLAG (see § 3.3). A write access to this register allows to freeze the values of Scaler L/H, Timer and Livetime L/H registers.

3.18 Timer High register (0x10, r)

Bit	Name	Function
15..0	TIMER_H	Acquisition Real Time (bits 31..16); LSB=1ms; enabled via Timers/scaler enable FLAG (see § 3.3).

3.19 Livetime Low register (0x11, r)

Bit	Name	Function
15..0	LIVETIME_L	Acquisition Live Time (bits 15..0) ; LSB=1ms; enabled via Timers/scaler enable FLAG (see § 3.3). Auto Gate mode: counts only if board is not full and Conversion logic state is Idle or Track. External Gate mode: counts only if board is not full and Conversion logic state is Track or Settling.

3.20 Livetime High register (0x12, r)

Bit	Name	Function
15..0	LIVETIME_H	Acquisition Live Time (bits 31..16) ; LSB=1ms; enabled via Timers/scaler enable FLAG (see § 3.3). Auto Gate mode: counts only if board is not full and Conversion logic state is Idle or Track. External Gate mode: counts only if board is not full and Conversion logic state is Track or Settling.

3.21 Software Clear register (0x13, w)

Bit	Name	Function
15..0	SW CLEAR	Any value written to this register generates a software clear which erases the buffer, timers and scalers

3.22 Software Reset register (0x14, w)

Bit	Name	Function
15..0	SW RESET	Any value written to this register generates a software reset which erases the buffer, timers and scalers; moreover it resets the FLAG CLEAR and reset Control FPGA state, see § 3.3

4. Software Tools

This section describes the CAEN Software package available on the board web page (**login required before to download**):

The software package is provided for Windows and Linux (32 and 64-bit) and mainly includes:

- A library for board configuration and raw data acquisition.
- A demo program to demonstrate the usage of the library.
- A program for firmware update.

The package for Windows contains also a set of LabView8.2 VIs (in the "LabView" folder) to allow for the module's control.

WARNING

For Windows Users and software tool releases < 2.03 (only 32-bit compliant):

Device driver for N957 board is automatically installed by the setup procedure.

The host PC should automatically load N957 drivers when connecting USB cable to a powered board. Anyway, if driver files (n957.inf, n957.sys) are requested during installation, they can be found into the following directories:

n957.inf :C:\Windows\inf

n957.sys: C:\Windows\System32\drivers

For Windows Users and software tool releases $\geq$ 2.03:

Device driver for N957 board are separately provided and available on the website.

For Linux Users and software tool releases > 2.03:

Device driver for N957 board are separately provided and available on the website (rel. 1.4 or higher).

In case of any driver installation issue, please contact CAEN Support (§ 6).

4.1 Software installation: Getting started

The following paragraphs will help through the module installation.

4.1.1 Software installation: Windows

1. Download the software package compliant to your operative system in the Firmware/Software table at the N957 web page.
2. Unzip the package on your computer; this will create a folder called "N957Tool" and several subfolders with files.

As installation is completed, the structure of the created folders will be as follows:




Fig. 4.1: Installation folder structure

4.1.1.1 Software installation: Demo folder

This folder provides demo application of the library: N957Demo

- *src*: provides the sources of the N957Demo application; it provides the compiled library file (.lib) of N957Tool library and the Visual C++ project file (.vcproj) of N957Demo.
- *include*: provides all the functions necessary to the operation and recompiling of the N957Demo application

4.1.1.2 Software installation: Doc folder

The Doc folder provides miscellaneous documentation on the N957Tool library

4.1.1.3 Software installation: LabView folder

The LabView folder contains a set of LabView8.2 VIs for the module's control

4.1.1.4 Software installation: Lib Folder

The Lib Folder contains the library N957lib.lib.

4.1.1.5 Software installation: Upgrade folder

This folder provides a console application for the firmware upgrade of the N957 module.

The structure of the applications menu appears as follows:




Fig. 4.2: Program menu demo

It is possible to read the release notes, the readme file, the documentation on the N957Tool library and the N957Demo application.

4.1.2 Driver installation (Windows)

NOTE: It is recommended to install the driver before to connect the hardware.

1. Download the USB driver compliant to your operating system in the Firmware/Software table at the N957 web page.
2. Unzip the package on your computer; the "N957Drv-X.Y.Z-x86_KK" will be generated (X.Y.Z is the driver release, while KK is 32 or 64).
3. Connect the USB cable's A-type connector to an available USB port on your PC.
4. Connect the USB cable's B-type connector to the USB port on your N957
5. Turn ON the NIM crate.
6. Windows will try to find drivers giving back a failure message; use the Window procedure to manually install the drivers and point to the driver folder on your computer. When the driver is properly installed, you will see it in the USB devices list of the Device Manager.




Fig. 4.3: USB driver installed.

7. Now the N957 is ready for operation.

Once installed, the USB driver is reloaded every time the USB cable connects the N957 board to the computer.

5. Library and Demo Software overview

5.1 N957Tool library

5.1.1 N957Tool library: Overview

N957Tool library is a C-language implemented software tool, which allows the Users to develop applications for operating the N957 board.




Fig. 5.1: Software layers

The library includes a set of functions grouped by purpose and hardware level

- *Board handling APIs*: allow the management of the board handler.
- *Miscellaneous APIs*: include miscellaneous functions (error decoding, library version etc.).
- *Level 0 APIs*: include lower level functions; allow to access directly the board registers, directly via their physical address.
- *Level 1 APIs*: include middle level functions; allow to access specified board functions, regardless the User's knowledge of the used registers addresses. Furthermore they provide memory flash read/write capabilities.
- *Level 2 APIs*: include higher level functions; allow to execute macro functions, such as data acquisition management, firmware upgrade, etc.

A set of files includes (*N957Lib.h*, *N957oslib.h*, *N957types.h*) all the APIs prototypes, declarations depending on the operating system, and data type required in order to develop applications based on the library.

5.1.2 N957Tool library: typical usage

The typical APIs usage is as follows:

- Obtain a valid board *handle* (*N957_Init*).
- Use the library APIs: *N957_####_...* all the APIs will use as input parameter, the board handle obtained in the previous step
- Release the board *handle* (*N957_End*).

5.2 Demo software

Demo software are N957Tool based applications developed for demonstrative purposes.

5.2.1 Demo software: N957Demo

5.2.1.1 N957Demo: overview

N957Demo is a command line application which shows the N957 operation using the APIs displayed by N957Lib.

Demo configures the board according to the parameters provided by the configuration files and executes readout cycles from the board itself. The result of readout (acquired measures) may be issued (if enabled by configuration files) on file in text format and hexadecimal representation. The acquired values are displayed in the form of histogram by applying external GnuPlot (rev $\geq$ 4.2).

Results of executed operations are displayed on video (with either ok or specific error message).

A special setting allows the board to produce samples for test and debug purposes.

5.2.1.2 N957Demo: settings

N957Demo can be configured via command line through a set of parameters here described.

The parameters format is as follows:

`-param_id[param_value]`

where:

- *param_id*: a character which identifies the parameter.
- *param_value*: value of the parameter, if foreseen by the parameter itself.

Notes about the parameters usage:

- If one parameter is not assigned, default value is assumed.
- The presentation order of the parameter is arbitrary:
- Each not recognized parameter is ignored
- Each parameter must be separated from the others via one or more spaces.
- The case of the parameters (id and value) is ignored.
- Do not type spaces between the parameter id and its value (example: -s100 OK, -s 100 WRONG)
- If the parameter value includes spaces (example: file names), these must be written between quotation marks without spaces after the parameter id (example: f" my config.conf")
- When the application is launched with parameter -h, it is displayed in the list of the available parameters.

List of available parameters with relevant default value and usage example:

f" my config.conf")-ffilename: output filename. If not specified 'N957Demo.conf' will be assumed.

Example:

- N957Demo -f"N957Demo.conf "
- N957Demo -FN957Demo.conf

-h: shows the help screen.

Example: N957Demo -h

5.2.1.3 N957Demo: configuration file format

The N957Demo configuration file allows setting the significant parameters. The file format is text type, structured in separate lines. For each line, initial spacing characters (spaces, tabs, etc.) are ignored.

param_id [param_value]

If the first character line is #, the line is considered Commentary and all content is ignored.

The valid lines (not comment) are structured as follows. where:

- param_id: a keyword that specifies the parameter.
- param_value: the value of the parameter, if provided by the same parameter.

param_id and param_value must be separated by at least a tab

Below is reported an example of configuration files, from which it is possible to obtain a list of defined parameters, their meaning and default value:

```
# *****
# N957Demo Configuration File
# *****
# Lines starting with # (first column) are comments

#
# The board number
BOARD_NUM          0

#
# path to the executable file of gnuplot
GNUPLOT_PATH       "."

#
# Save readout data into the Output File (0=don't save)
LOG_TO_FILE        0

#
# Readout data Output Filename ( meaningful only for LOG_TO_FILE!= 0)
LOG_FILENAME       "data.log"

#
# Maximum number of samples to acquire (-1 means no limit)
MAX_NUM_SAMPLES    -1

#
# Data Block dimension [1..65536]
DATA_BLOCK_DIM     32768

#
# Debug mode (0= debug disabled)
DEBUG              0

#
# Acquisition mode: (0= Ext Gate 1= Auto)
ACQ_MODE           1

#
```

```
# Gnu plot refresh rate (msec)
GNU_PLOT_REFRESH      500
```

```
#
# Gnu plot X scale factor
GNU_PLOT_X_SCALE      0.3
```

```
# Acquisition duration expressed in seconds, 0 => manual stop.
ACQUISITION_DURATION  0
```

5.2.1.4 N957Demo: output data format

This is a text format output file; on each row it provides data readout from the board in hexadecimal format. The file is generated only if the parameter configuration file LOG_TO_FILE is set to 1: the output filename is specified by the configuration file parameter LOG_FILENAME.

Example:

```
.....
07c8
07c9
07ca
07c9
07c9
.....
```

5.2.1.5 N957Demo: practical example

In the Demo folder, the N957Demo.exe file is a simple practical example of controlling the N957 board. Here follows a step-by-step procedure (Windows) to use it for acquiring, plotting and saving data from an hardware set-up consisting in:

Nal detector + PMT + N914 + N968 + N957

where:

N914 is CAEN Analog Pulse Processor.

N968 is CAEN Spectroscopy Amplifier.

1. Customize the N957Demo.conf file: e.g. enable data saving (LOG_TO_FILE 1); set the output filename (LOG_FILENAME "output.log"); set the acquisition mode by (ACQUISITION_DURATION = 0 for manual, ACQUISITION_DURATION ≠ 0 for automatic time-driven stop).
2. Save the configuration file settings.
3. Double click on the N957Demo.exe file:




Fig. 5.2: N957Demo prompt

4. Type 's' on your keyboard to start the acquisition:




Fig. 5.3: N975Demo in acquisition mode

Together with the acquisition, also the histogram plotting starts:




Fig. 5.4: Histogram plot of ^{60}Co source in progress

Type 'r' key to reset the histogram and the 'p' key to pause/resume the acquisition.

5. Type 's' key to stop the acquisition session (if you have set the manual acquisition mode):

```

C:\Program Files\CAEN\N957Tool\Demo\N957Demo.exe
-----
N 9 5 7   D E M O
-----
www.caen.it                               rev.02.02
-----
Reading Configuration File N957Demo.conf
N957 FW Rev. 00.00
Hit 's' to start acquisition mode , any other to quit ...

ADC Conversions Number : 0
Time (ms) : 0
Live Time (ms) : 0
N957 Start Acquisition mode 1 : Ok
Acquisition running ...

Hit 'r' to reset histogram, any other to quit ...
Hit 'p' to pause/resume, any other to quit ...
Any other to quit ...
ADC Conversions Number : 2522
Time (ms) : 1488382
Live Time (ms) : 1487918
Hit any key to exit..._

```

Fig. 5.5: Acquisition report

The acquisition report is displayed, with the number of the input signal samples (ADC Conversions Number) and the contents of the two board's 32-bit timers (Timer and Live Time).

6. Type any key to quit the program.

Raw data (i.e. the samples of the digitized input signal) are saved into the *output.log* file, according to the configuration file. The histogram data are saved into the *hist.dat* file.

Note that, in the src folder, the sources of the N957Demo application are provided as reference to those users who want to develop their own control software basing on this demo.

6. Technical Support

To contact CAEN specialists for requests on the software, hardware, and board return and repair, it is necessary a MyCAEN+ account on www.caen.it:

<https://www.caen.it/support-services/getting-started-with-mycaen-portal/>

All the instructions for use the Support platform are in the document:



A paper copy of the document is delivered with CAEN boards.

The document is downloadable for free in PDF digital format at:

https://www.caen.it/wp-content/uploads/2022/11/Safety_information_Product_support_W.pdf