


Register your device

Register your device to your **MyCAEN+** account and get access to our customer services, such as notification for new firmware or software upgrade, tracking service procedures or open a ticket for assistance. **MyCAEN+** accounts have a dedicated support service for their registered products. A set of basic information can be shared with the operator, speeding up the troubleshooting process and improving the efficiency of the support interactions.

MyCAEN+ dashboard is designed to offer you a direct access to all our after sales services. Registration is totally free, to create an account go to <https://www.caen.it/become-mycaenplus-user> and fill the registration form with your data.



<https://www.caen.it/become-mycaenplus-user/>

Purpose of this Manual

This document is the A1561H-AG561H 12 Channel 6 kV/20 µA Power Supply Boards user manual; it contains information about the installation, the configuration and the use of the board.

Change Document Record

Date	Revision	Changes
30 September 2014	0	PRELIMINARY Release
1 April 2016	1	Updated with AG561H
06 February 2018	2	Updated technical specification
28 May 2019	3	Updated technical specification
10 July 2019	4	Updated Output control and monitoring
14 April 2020	5	Updated Overview
14 February 2022	6	Updated technical specification
5 September 2024	7	Updated technical specification

Symbols, abbreviated terms and notation

T.B.D.

Reference Documents

SY4527 User's Manual

Disclaimer


No part of this manual may be reproduced in any form or by any means, electronic, mechanical, recording, or otherwise, without the prior written permission of CAEN SpA.

CAEN will repair or replace any product within the guarantee period if the Guarantor declares that the product is defective due to workmanship or materials and has not been caused by mishandling, negligence on behalf of the User, accident or any abnormal conditions or operations.

CAEN declines all responsibility for damages or injuries caused by an improper use of the Modules due to negligence on behalf of the User. It is strongly recommended to read thoroughly the CAEN User's Manual before any kind of operation. *CAEN reserves the right to change partially or entirely the contents of this Manual at any time and without giving any notice.*

Disposal of the Product *The product must never be dumped in the Municipal Waste. Please check your local regulations for disposal of electronics products.*

Made In Italy : We stress the fact that all the boards are made in Italy because in this globalized world, where getting the lowest possible price for products sometimes translates into poor pay and working conditions for the people who make them, at least you know that who made your board was reasonably paid and worked in a safe environment. (this obviously applies only to the boards marked "Made in Italy", we cannot attest to the manufacturing process of "third party" boards).



Index

1. Overview.....	4
Functional description	4
Channel Characteristic Table	5
Front Panel	6
Technical Specifications.....	7
Packaging	7
External connections.....	7
2. Safety and installation requirements.....	8
General safety information.....	8
Injury Precautions	8
Safety Terms and Symbols on the Product.....	8
Installation	8
3. Operating modes.....	9
Output control and monitoring	9
Output Enable.....	10
Grounding specifications (A1561H)	10

List of Figures

Fig. 1 – Ax561H front panel	6
Fig. 2 – INTERLOCK connector	10
Fig. 3 – JA jumper location.....	11
Fig. 4 – Earth configuration connection examples.....	11

List of Tables

Table 1 – Channel characteristics of the Mod. Ax561H HV Board.....	5
--	---

1. Overview

Functional description

The Mod. A1561H is a 12 channel HV board, available with either positive or negative polarity, compatible with the CAEN Universal Multichannel Power Supply System¹ (SY1527, SY2527, SY4527, SY5527).

The HV channels share a common floating return, which allows on-detector grounding reducing the noise level; the floating return is insulated from the crate earth up to ± 50 V (with a 65 V hardware limit).

The AG561H is the “common ground” version of the board: the return of the HV channels is wired to the crate Earth reference.

The output voltage range is $0 \div 6$ kV, with 20 μ A maximum output current.

The board is provided with both current and voltage protections. If overcurrent occurs, the relevant channel can be programmed either to turn off after a programmable trip time or to keep on providing the maximum allowed current: this particular feature allows the modules to work as current generator. The maximum output voltage can be fixed, through a potentiometer located on the front panel, at the same common value for all the board channels and this value can be read out via software.

The HV RAMP-UP and RAMP-DOWN rates may be selected independently for each channel in the $1 \div 500$ V/s range (1 V/s step).

The HV output is delivered by SHV connectors. The boards have also the safety board interlock: this protection allows to disable the primary HV generation when the HV outputs are not connected to their loads. The unit is available with either positive, negative or “mixed” (half of the channels positive and half negative) polarity.

¹ SYx527 shall run the latest available firmware release

Channel Characteristic Table

Table 1 – Channel characteristics of the Mod. Ax561H HV Board

Polarity	Positive, Negative or Mixed depending on purchased version; on "Mixed" version: CH0..5 positive, CH6..11 negative	
Output Voltage	0÷6 kV	
Max. Output Current	20 μ A	
Voltage Set Resolution	100 mV	
Voltage Monitor Resolution	10 mV	
Current Set Resolution	500 pA	
Current Monitor Resolution	50 pA	
VMAX hardware	0÷6 kV common for all the board channels	
VMAX hardware accuracy	\pm 2% of FSR	
VMAX software	0÷6 kV settable for each channel	
VMAX software resolution	1 V	
Ramp Up/Down	1÷500 Volt/sec, 1 Volt/sec step	
Voltage Ripple ²	10 ÷ 1000 Hz	Typ
	Max	5mVpp
Accuracy ^{3,4}	1 ÷ 20000 kHz	Typ
	Max	10mVpp
Accuracy ^{3,4}	VMon vs. VOut	3mVpp
	Max	5mVpp
	VSet vs. VOut	\pm 0.02% \pm 1.2 V
	IMoN vs. IOut	\pm 0.02% \pm 1.2 V
Accuracy ^{3,4}	ISet vs. IOut	\pm 0.2% \pm 40 nA
		\pm 0.2% \pm 40 nA

² Ripple may exceed such limits whenever OVC and UNV occur (see Output control and monitoring)

³ From 1% to 100% of Full Scale Range

⁴ During operation in Overcurrent or when VMAX Hardware is reached (and/or exceeded), VMON values have to be assumed as "indication"; possible monitor drifts are caused by the different regulation mode.

Front Panel




Fig. 1 – Ax561H front panel

Technical Specifications

Packaging

Single width board (5 TE); height is 6U.

External connections



WARNING! HV output connectors produce extremely hazardous voltages at a potentially lethal current level; never connect or disconnect the HV OUT connector with the SYx527 power ON/OFF switch ON; always switch SYx527 power OFF and wait at least 30s before connecting or disconnecting HV cables.

The function and electro-mechanical specifications of the external connectors are as follows:

Output Channels (0...11): HV coaxial connectors; SHV RADIALL R317580; Impedance: 50 Ohm; Frequency range: 0 – 2 GHz; VSWR: <1.20 + 0.3 F (GHz) – (plug and jack); Test voltage: 10kV DC – 1mn (unmated), 12kV DC – 1mn (mated pairs); Current rating: 10 A

INTERLOCK: AMP 280371-2 connector

Displays:

HV ON LED: Function: lights up as at least one channel is on.

Type: red LEDs for positive polarity; yellow LEDs for negative polarity

INTERLOCK LED: Function: lights up as the board is in INTERLOCK (channel are disabled).

Type: red LED

Other components:

VMAX trimmer: allows to adjust the hardware maximum voltage VMAX common to all channels.

Its value can be read out via software.

JA: Jumper connector; short circuit: connect FAGND and AGND; see p.10

2. Safety and installation requirements

General safety information

This section contains the fundamental safety rules for the installation and operation of the board. Read thoroughly this section before starting any procedure of installation or operation of the product.

Injury Precautions

Review the following precautions to avoid injury and prevent damage to this product or any products connected to it. To avoid potential hazards, use the product only as specified. Only qualified personnel should perform service procedures.

Avoid Electric Overload.

To avoid electric shock or fire hazard, do not power a load outside of its specified range.

Avoid Electric Shock.

To avoid injury or loss of life, do not connect or disconnect cables while they are connected to a voltage source.

Do Not Operate Without Covers.

To avoid electric shock or fire hazard, do not operate this product with covers or panels removed.

Do Not Operate in Wet/Damp Conditions.

To avoid electric shock, do not operate this product in wet or damp conditions.

Do Not Operate in an Explosive Atmosphere.

To avoid injury or fire hazard, do not operate this product in an explosive atmosphere.

Do Not Operate With Suspected Failures.

If you suspect this product to be damaged, have it inspected by qualified service personnel.

Safety Terms and Symbols on the Product

These terms may appear on the product:

DANGER indicates an injury hazard immediately accessible as you read the marking.

WARNING indicates an injury hazard not immediately accessible as you read the marking.

CAUTION indicates a hazard to property including the product.

The following symbols may appear on the product:



DANGER
High Voltage



WARNING
Refer to Manual

Installation

The Mod. Ax561H is a SYx527 board. At power ON the SYSTEM, the processor will scan all the slots in the crate to find out where the module is plugged and what kind of module it is.

3. Operating modes

The HV board can be controlled, either locally or remotely, through the SYSTEM software interface. For details on SYSTEM operation, please refer to the User's Manual of this product. The following sections contain a description of commands available for the board control and status monitoring.

Output control and monitoring

For each output channel, it is possible, through the system, to access the following parameters:

<i>CHANNEL NAME (settable):</i>	descriptive name for the relevant channel
<i>VOSET (settable):</i>	the first of the two allowed voltage programmable values.
<i>IOSET (settable):</i>	the first of the two allowed current limit programmable values
<i>V1SET (settable):</i>	the second of the two allowed voltage programmable values
<i>I1SET (settable):</i>	the second of the two allowed current limit programmable values
<i>RUp (settable):</i>	the Ramp-Up parameter value, i.e. the maximum voltage programmable increase rate.
<i>RDWn (settable):</i>	the Ramp-Down parameter value, i.e. the maximum voltage programmable decrease rate.
<i>TRIP (settable):</i>	the TRIP parameter value, i.e. the maximum time an Over Current condition is allowed to last.
<i>SVMAX (settable):</i>	the maximum voltage value programmable for the channel. If the value set as SVMAX is less than the current value of the VOSET/ V1SET parameter, the latter will automatically decrease to the SVMAX value.
<i>VMON (monitor):</i>	monitored voltage value
<i>IMON (monitor):</i>	monitored current value
<i>ZCDetect (settable):</i>	(ON/OFF) If ON, it stores the present IMON value into memory for "zero current compensation" purposes, see ZCAdjust parameter (this parameter is available only for some versions, please contact CAEN)
<i>ZCAdjust (settable):</i>	(EN/DIS) If enabled, the stored IMON value via ZCDetect option is subtracted from the measured, "non compensated" IMON value. The returned "compensated" IMON value will be then the difference between measured and stored values; if disabled, the returned IMON value is not compensated (this parameter is available only for some versions, please contact CAEN)
<i>STATUS (monitor):</i>	it displays the channel status.
<i>PW (ON/OFF):</i>	the Power parameter shows the ON/OFF channel status. As this parameter is set ON, the channel is switched on (if the INTERLOCK is not active and if the channel is enabled either locally or remotely) highlighted in green when channel ON; onstate = ON; offstate = OFF
<i>POn (EN/DIS):</i>	Power-On option, which can be enabled or disabled. If this option is enabled, at Power-On or after a Restart each channel is restored in the same condition (defined by the Power parameter) it was before the Power-Off or Reset. If this option is disabled, at Power-On or after a Restart all the channels are off, independently from the condition in which they were before the Power-Off or Reset ; onstate = Enabled; offstate = Disabled
<i>PDwn (Kill/Ramp):</i>	Power-Down option, which can be set as KILL or RAMP. It affects the way the channels react at a Power-Off command caused by a TRIP condition. If the KILL option is selected, the relevant channel will be switched off at the maximum rate available. If the RAMP option is selected, the voltage will drop to zero at a rate determined by the value of the Ramp-Down parameter programmed for that channel; onstate = Ramp; offstate = Kill
<i>TripInt:</i>	2N-bit word (hexadecimal) maximum 16 lines, where N is the number of the board's Internal Trip Bus lines. Bits [0;N-1] allow the channel to sense the trip status from the corresponding lines when set to one; in the same way, bits [N;2N-1] allow the channel to propagate the trip status over the Trip Bus: bit N on line 0 and so on (see SY4527 User's manual).
<i>TripExt:</i>	Must be set in the 0÷255 range (hexadecimal). Bits [0;3] allow the channel to sense the trip status from the corresponding lines when set to one; in the same way, bits [4;7] allow the channel to propagate the trip status over the trip bus: bit 4 on line 0 and so on (see SY4527 User's manual).

If the POWER ON option is enabled, as the module is turned ON, the channel is restored to the same condition it was before the POWER OFF or RESET; if this option is disabled, at POWER ON or after a RESET, the channel is kept OFF independently from its previous condition.

The following messages may be returned by the SYSTEM when monitoring the channel status:

OFF	(channel turned OFF)
RUP	(channel ramping up)
RDWN	(channel ramping down)
OVC	(channel in OVERCURRENT condition)
OVV	(channel in OVERVOLTAGE condition)
UNV	(channel in UNDERRVOLTAGE condition) ⁵
E-TRIPPED	(channel OFF due to external TRIP line signal) ⁶
I-TRIPPED	(channel OFF due to internal OVERCURRENT condition)
EXT_DIS	(channel disabled by board INTERLOCK protection)
Moreover it is possible to monitor board parameters, such as measured Temperature and HVMax, and to check board status; the following messages may be returned by the POWER SUPPLY SYSTEM when monitoring the board status:	
UNDER_TEMP	(board temperature < 5°C)
OVER_TEMP	(board temperature > 65°C)

Output Enable



Fig. 2 – INTERLOCK connector

The enable procedure is completed in one of the following ways:

- short the PASSIVE INTERLOCK (see also p. 7) pins (lower couple).
- supply the SIGNAL INTERLOCK (see also p. 7) pins (higher couple) with a +5 V (3-4mA) differential signal.

The INTERLOCK LED (red) is turned off as one of the actions above is performed.

When the channels are disabled the voltage outputs drop to zero at the maximum rate available; when the output disable cause is removed (see above), the channels remain OFF until the User turns them ON via software.

Grounding specifications (A1561H)

The HV channels share a common floating return (FAGND), insulated from the crate ground (AGND). This feature allows on-detector grounding, thus avoiding loops which may increase noise level. FAGND and AGND may be connected, by short circuiting JA jumper pins on the motherboard (see figure below). The protection shield must be screwed off in order to access JA.

⁵ UNV is also reported when Hvmax limit is reached, it is up to the User to verify that VMON value does not exceed HVMAX.

⁶ EXTTRIP and INTTRIP parameters are expressed in Hexadecimal format




Fig. 3 – JA jumper location

Safety Earth connection

The connection of return to Earth is fundamental for User safety. The connection must always be at the level of detector or power supply system. Return connection even if not present or performed incorrectly, due to protection circuits implemented on the board, are bound to Earth; in this case the voltage difference between return and Earth (System), is limited to approximately 50V. Please note that this is a status of emergency-protection, not a working one. The JA jumper allows to optimize the connection of the return and of AGND (Earth). The best configuration must be determined by the user upon application, the optimal connection depends on many characteristics of the related experiment. The following diagrams show two examples of configuration, namely:

- The “closed loop” Earth configuration (JA contacts closed)
- The “open loop” Earth configuration (JA contacts open)




Fig. 4 – Earth configuration connection examples

**CAEN S.p.A.**

Via Vetraia 11
55049 - Viareggio
Italy
Phone +39 0584 388 398
Fax +39 0584 388 959
info@caen.it
www.caen.it

**CAEN GmbH**

Brunnenweg 9
64331 Weiterstadt
Germany
Tel. +49 (0)212 254 4077
Mobile +49 (0)151 16 548 484
info@caen-de.com
www.caen-de.com

CAEN Technologies, Inc.

1 Edgewater Street - Suite 101
Staten Island, NY 10305
USA
Phone: +1 (718) 981-0401
Fax: +1 (718) 556-9185
info@caentechnologies.com
www.caentechnologies.com

CAENspa INDIA Private Limited

B205, BLDG42, B Wing,
Azad Nagar Sangam CHS,
Mhada Layout, Azad Nagar, Andheri (W)
Mumbai, Mumbai City,
Maharashtra, India, 400053
info@caen-india.in
www.caen-india.in



Copyright © CAEN SpA. All rights reserved. Information in this publication supersedes all earlier versions. Specifications subject to change without notice.