


Register your device

Register your device to your **MyCAEN+** account and get access to our customer services, such as notification for new firmware or software upgrade, tracking service procedures or open a ticket for assistance. **MyCAEN+** accounts have a dedicated support service for their registered products. A set of basic information can be shared with the operator, speeding up the troubleshooting process and improving the efficiency of the support interactions.

MyCAEN+ dashboard is designed to offer you a direct access to all our after sales services. Registration is totally free, to create an account go to <https://www.caen.it/become-mycaenplus-user> and fill the registration form with your data.



<https://www.caen.it/become-mycaenplus-user/>

Technical Information Manual

Revision n. 3
2 September 2013


MOD. A 1821 series
HIGH VOLTAGE
BOARD
MANUAL REV.3

CAEN will repair or replace any product within the guarantee period if the Guarantor declares that the product is defective due to workmanship or materials and has not been caused by mishandling, negligence on behalf of the User, accident or any abnormal conditions or operations.

CAEN declines all responsibility for damages or injuries caused by an improper use of the Modules due to negligence on behalf of the User. It is strongly recommended to read thoroughly the CAEN User's Manual before any kind of operation.



CAEN reserves the right to change partially or entirely the contents of this Manual at any time and without giving any notice.



Disposal of the Product *The product must never be dumped in the Municipal Waste. Please check your local regulations for disposal of electronics products.*

Made In Italy : We stress the fact that all the boards are made in Italy because in this globalized world, where getting the lowest possible price for products sometimes translates into poor pay and working conditions for the people who make them, at least you know that who made your board was reasonably paid and worked in a safe environment. (this obviously applies only to the boards marked "Made in Italy", we cannot attest to the manufacturing process of "third party" boards).

TABLE OF CONTENTS

| | |
|--|-----------|
| 1. OVERVIEW | 5 |
| 1.1 FUNCTIONAL DESCRIPTION..... | 5 |
| 1.2 CHANNEL CHARACTERISTICS TABLE | 6 |
| 1.3 FRONT PANEL..... | 7 |
| 1.4 TECHNICAL SPECIFICATIONS | 8 |
| 1.4.1 <i>Packaging</i> | 8 |
| 1.4.2 <i>External connections</i> | 8 |
| 1.4.3 <i>Displays</i> | 8 |
| 1.4.4 <i>Other components</i> | 8 |
| 2. SAFETY INFORMATION AND INSTALLATION REQUIREMENTS | 9 |
| 2.1 GENERAL SAFETY INFORMATION..... | 9 |
| 2.1.1 <i>Injury Precautions</i> | 9 |
| 2.2 SAFETY TERMS AND SYMBOLS ON THE PRODUCT | 10 |
| 2.3 INSTALLATION..... | 10 |
| 3. OPERATING MODES | 11 |
| 3.1 OUTPUT CONTROL AND MONITORING | 11 |
| 3.2 OUTPUT ENABLE | 12 |
| 3.3 FULL SCALE RANGE SETTING | 12 |

LIST OF FIGURES

| | |
|--|----|
| FIG. 1.1 – MOD. A1821 SERIES FRONT PANEL..... | 7 |
| FIG. 3.1 – MOD A1821 SERIES SIDE VIEW | 12 |
| FIG. 3.2 – FULL SCALE RANGE DIP-SWITCH TOP VIEW..... | 13 |

LIST OF TABLES

| | |
|---|---|
| TABLE 1.1 - CHANNEL CHARACTERISTICS OF THE A1821 SERIES | 6 |
|---|---|

1. Overview

1.1 Functional description

The Model A 1821 board houses 12 H.V. channels with either positive (A 1821P) or negative (A 1821N) polarity. The Mod. A 1821 output channels offer either 3 kV / 200 μ A or 3 kV / 20 μ A full scale range (dip-switch selectable). The Model A 1821H board houses 12 H.V. channels with either positive (A 1821HP) or negative (A 1821HN) polarity. The Mod. A 1821H output channels offer either 3 kV / 200 μ A or 3 kV / 10 μ A full scale range (dip-switch selectable). Two special versions with different channel configuration (A1821HM and A1821HMP are also available). All boards are compatible with the CAEN Universal Multichannel Power Supply System (SYx527).

If the output voltage differs from the programmed value by more than 3% of voltage full scale range, the channel is signalled to be either in OVERVOLTAGE or UNDERVOLTAGE condition. Moreover, for each channel, a voltage protection limit SVMAX can be fixed via software with 1 V resolution and the output voltage can not be programmed beyond this value.

The HV RAMP-UP and RAMP-DOWN rates may be selected independently for each channel in the range 1 \div 500 V/s in 1 V/s steps.

The output current is monitored with 2 nA / 20 nA resolution depending on current range; if a channel tries to draw a current larger than its programmed limit it is signalled to be in OVERCURRENT condition; the SY 1527 system detects this state as a fault and reacts according to the setting of the TRIP parameter, namely:

1) TRIP=infinite (= 1000 s)

When the set output current value is reached the channel behaves like a constant current generator.

2) TRIP=finite (< 1000 s)

The output current keeps the set value only for programmed time interval and then is switched off.

The TRIP time (i.e. the maximum time an OVERCURRENT condition is allowed to last) can be programmed in 0.1 s steps.

The maximum output voltage (VMAX Hardware) can be fixed, through a potentiometer located on the front panel, at the same common value for all the board channels and this value can be read out via software.

The boards host also a temperature sensor located on the PCB near the HV channels: the temperature values measured by this sensor are used to signal Over Temperature condition on the POWER SUPPLY SYSTEM.

The boards are provided with an "HV EN" input that disables the channels when it is not connected to ground

1.2 Channel Characteristics Table

Table 1.1 - Channel characteristics of the A1821 series

| | | |
|---|---|--|
| Channel | A1821 (ch 0..11), A1821H (ch 0..11), A1821HM (0..9), A1821HMP (0..9) | A1821HM (ch 10, 11), A1821HMP (ch 10, 11) |
| Polarity: | A1821/A1821H: Positive / Negative depending on version A1821HM: ch0..5 neg; ch6..9 pos A1821HMP: Positive | A1821HM: negative; A1821HMP: Positive |
| Output Voltage: | 0÷3 kV | 0÷6 kV |
| Max. Output Current: | high range 200 μ A low range 20 μ A (A1821)/10 μ A (A1821H, A1821HM, A1821HMP) | low range 200 μ A high range 1 mA |
| Voltage Set/Monitor Resolution: | 250 mV | 500 mV |
| Current Set/Monitor Resolution: | 20 nA / 2 nA depending on current range (A1821) 20 nA / 1 nA depending on current range (A1821H, A1821HM, A1821HMP) | 20 nA / 100 nA depending on current range |
| VMAX hardware: | 0÷3 kV common for all the board channels | 0÷6 kV common for all the board channels |
| VMAX hardware accuracy: | ± 2% | ± 2% |
| VMAX software: | 0÷3 kV settable for each channel | 0÷6 kV settable for each channel |
| VMAX software resolution: | 1 V | 1 V |
| Ramp Up/Down: | 1÷500 Volt/sec, 1 Volt/sec step | 1÷500 Volt/sec, 1 Volt/sec step |
| Voltage Ripple:¹ | < 30 mV pp | < 30 mV pp |
| Voltage Monitor vs. Output Voltage Accuracy:² | ± 0.3% ± 0.5 V | ± 0.3% ± 1 V |
| Voltage Set vs. Voltage Monitor Accuracy:² | ± 0.3% ± 0.25 V | ± 0.3% ± 0.5 V |
| Current Monitor vs. Output Current Accuracy:² | ± 2% ± 0.01 μ A (A1821 low range) ± 2% ± 0.005 μ A (A1821H, A1821HM, A1821HMP low range) ± 2% ± 0.1 μ A (high range) | ± 2% ± 0.5 μ A (1 mA range) ± 2% ± 0.1 μ A (200 μ A range) |
| Current Set vs. Current Monitor Accuracy:² | ± 2% ± 0.002 μ A (A1821 low range) ± 2% ± 0.001 μ A (A1821H, A1821HM, A1821HMP low range) ± 2% ± 0.02 μ A (high range) | ± 2% ± 0.1 μ A (1 mA range) ± 2% ± 0.02 μ A (200 μ A range) |
| Threshold temperature parameters (TMIN, TMAX) | +5 ÷ +65 °C | +5 ÷ +65 °C |

¹ From 10 Hz to 15 MHz at full load

² From 10% to 90% of Full Scale Range

1.3 Front Panel




Fig. 1.1 – Mod. A1821 SERIES front panel

1.4 Technical Specifications

1.4.1 Packaging

The module is housed in a 5TE-wide, 6U-high mechanics.

1.4.2 External connections

The location of all components of the front panel is shown in Fig. 2.1, p. 8. The function and electro-mechanical specifications of the external connectors are listed in the following subsections.

CH 0...11 HV CONNECTORS:

Mechanical specifications:

HV coaxial connectors

Radiall SHVR317580-type

Electrical specification: high voltage output according to specifications given in Table 2.1, p. **Errore. Il segnalibro non è definito..**

HV EN CONNECTOR

Mechanical specifications:

00-type LEMO connector.

Electrical specifications: board ENABLE input, if it is connected to ground, the channels are enabled. Refer to § 4.2, p.12 for further details.

1.4.3 Displays

CH ON 0..11 LEDs:

Function: they light up as the relevant channel is on.

Type: red LEDs for positive polarity version; yellow LEDs for negative polarity version

1.4.4 Other components

VMAX trimmer:

Function: it allows to adjust the hardware maximum voltage VMAX common to all the channels. Its value can be read out via software.

2. Safety information and installation requirements

2.1 General safety information

This section contains the fundamental safety rules for the installation and operation of the boards. Read thoroughly this section before starting any procedure of installation or operation of the product.

2.1.1 *Injury Precautions*

Review the following precautions to avoid injury and prevent damage to this product or any products connected to it. To avoid potential hazards, use the product only as specified. Only qualified personnel should perform service procedures.

Avoid Electric Overload.

To avoid electric shock or fire hazard, do not apply a voltage to a load that is outside the range specified for that load.

Avoid Electric Shock.

To avoid injury or loss of life, do not connect or disconnect cables while they are connected to a voltage source.

Do Not Operate Without Covers.

To avoid electric shock or fire hazard, do not operate this product with covers or panels removed.

Do Not Operate in Wet/Damp Conditions.

To avoid electric shock, do not operate this product in wet or damp conditions.

Do Not Operate in an Explosive Atmosphere.

To avoid injury or fire hazard, do not operate this product in an explosive atmosphere.

Do Not Operate With Suspected Failures.

If you suspect there is damage to this product, have it inspected by qualified service personnel.

2.2 Safety Terms and Symbols on the Product

These terms may appear on the product:

- **DANGER** indicates an injury hazard immediately accessible as you read the marking.
- **WARNING** indicates an injury hazard not immediately accessible as you read the marking.
- **CAUTION** indicates a hazard to property including the product.

The following symbols may appear on the product:



DANGER

High Voltage



ATTENTION

Refer to Manual

2.3 Installation

The Mod. A1821 SERIES is a single-width board (5 TE-wide) which can be inserted in any slot of the SYX527 crate. At power ON the SYX527 system processor will scan all the slots in the crate to find out where the module is plugged and what kind of module it is.

3. Operating modes

The Mod. A1821 SERIES board can be controlled, either locally or remotely, through the SYX527 software interface. For details on SYX527 system operation, please refer to the User's Manual of this product. The following sections contain a description of commands available for the board control and status monitoring.



ATTENTION

THE MOD. A1821 SERIES BOARD REQUIRES
SYX527 FIRMWARE VERSION 1.09.04 OR LATER

3.1 Output control and monitoring

For each output channel, it is possible, through the SY 1527 system, to perform the following operations:

- Assign to channel a symbolic name
- Set output voltage (VSET)
- Set max. output current (ISET)
- Set output voltage software limit (SVMAX)
- Set voltage ramp-up speed (RAMP-UP)
- Set voltage ramp-down speed (RAMP-DOWN)
- Set TRIP parameter
- Enable/disable POWER ON option
- Switch channel ON/OFF
- Monitor output voltage (VMON)
- Monitor output current (IMON)
- Monitor channel status

If the POWER ON option is enabled, the channel, at POWER ON, is restored in the same condition it was before the POWER OFF or RESET; if this option is disabled, at POWER ON or after a RESET, the channel is kept OFF independently from its previous condition.

The following messages may be returned by the SYX527 when monitoring the channel status:

- OFF (channel turned OFF)
- RUP (channel ramping up)
- RDWN (channel ramping down)
- OVC (channel in OVERCURRENT condition)
- OVV (channel in OVERVOLTAGE condition)

- UNV (channel in UNDERVOLTAGE condition)
- EXTTRIP (channel OFF due to external TRIP line signal)
- INTTRIP (channel OFF due to internal OVERCURRENT condition)
- EXT_DIS (channel disabled by board INTERLOCK protection)

Moreover it is possible to monitor board temperature and to check board status; the following messages may be returned by the SYX527 when monitoring the board status:

- UNDER_TEMP (board temperature < 5°C)
- OVER_TEMP (board temperature > 65°C)

3.2 Output Enable

The board is provided with an "HV EN" input that enables the channels when it is connected to ground.

When the channels are disabled the voltage outputs drop to zero at the maximum rate available; when the output disable cause is removed, i. e. the "HV EN" connector is connected to ground, the channels remain OFF until the User turns them ON via software.

3.3 Full scale range setting

The output voltage and current full scale range, common to all channels, can be selected by dip-switches (please refer to the figure below for the dip-switches location on the board).




Fig. 3.1 – Mod A1821 SERIES side view

In order to select the desired current Full Scale Range (common to all channels), the dip-switch must be set, by looking at the board's top side, as illustrated in Fig. 4.3.

Current range selection must be performed before inserting the board into the crate.

Default factory setting is 20 μ A Full Scale Range.

Top view





Fig. 3.2 – Full scale range dip-switch top view

**CAEN S.p.A.**

Via Vetraia 11
55049 - Viareggio
Italy
Phone +39 0584 388 398
Fax +39 0584 388 959
info@caen.it
www.caen.it

**CAEN GmbH**

Brunnenweg 9
64331 Weiterstadt
Germany
Tel. +49 (0)212 254 4077
Mobile +49 (0)151 16 548 484
info@caen-de.com
www.caen-de.com

CAEN Technologies, Inc.

1 Edgewater Street - Suite 101
Staten Island, NY 10305
USA
Phone: +1 (718) 981-0401
Fax: +1 (718) 556-9185
info@caentechnologies.com
www.caentechnologies.com

CAENspa INDIA Private Limited

B205, BLDG42, B Wing,
Azad Nagar Sangam CHS,
Mhada Layout, Azad Nagar, Andheri (W)
Mumbai, Mumbai City,
Maharashtra, India, 400053
info@caen-india.in
www.caen-india.in



Copyright © CAEN SpA. All rights reserved. Information in this publication supersedes all earlier versions. Specifications subject to change without notice.